FRONT PANEL

(a)mO Ø 0 Q ۵ 1301

 \bigcirc

+

 \bigcirc

INSTRUCTIONS FOR FIXING TO THE WALL

DRILLING TEMPLATE

USE NO.8 ROUND HEAD SCREWS

UNIT MAY BE MOUNTED VERTICALLY **OR HORIZONTALLY**

IMPORTANT

USE 4 WALL FASTENERS, EACH CAPABLE OF SUPPORTING 4.77kg / 10lb 8oz, TO PROVIDE A SAFETY FACTOR OF 4. USE APPROPRIATE FIXINGS, PLUGS OR ANCHORS, FOR THE TYPE OF WALL THE UNIT IS TO BE MOUNTED ON.

INSTRUCTIONS FOR FITTING THE WALL MOUNT BRACKETS

REMOVE ALL RUBBER FEET **ORIENTATE BRACKETS AS SHOWN** FIT BRACKETS TO UNIT USING SCREWS AND WASHERS SUPPLIED (4 off M3 x 6 Pan TORX) DO NOT USE SCREWS USED TO FIT THE RUBBER FEET **TORX T10 DRIVER IS REQUIRED**

UP47701-1



